

FIG. 1


21 1/2"
23 1/2"
204
CONTROL PANEL
22 1/2"
33 3/8" - 34 1/8"
5 7/8"
3 3/4" - 4 1/2"
1 1/2"
Lint Filter Access Panel
201
Washing machine
Control panel
Control knob
Digital Display
Porthole
Window
Top access panel
Housing Body
Lint Filter Access Panel
202
Related Documents:
Porthole model
Angled control panel
Advanced Novotronic controls
Single knob operation
Hydromatic wash system
Scoop and ladle fin system
Extended wash programs
Top wash temperature of 190°F
Quick Wash 105°F program
Short wash program
Program sequence lights
Automatic water levels
Water Plus option
Gentle Wash option
Prewash option
Top spin speed of 1200 RPM
Low water consumption
Fault indicators
Self diagnostics
Cast iron cradle
Hydraulic suspension
Available in white only
Available in right hinge only
Utilizes WTV319A stacking kit
Error conditions:
No power
No response to control settings
Fault indicators
Door will not open
Clothes are not clean
Functionality:
Extended wash programs
Quick Wash 105°F program
Short wash program
Program sequence lights
Gentle Wash option
Prewash option
Spin
Rinse
Fill
Fault indicators
Self diagnostics
Actions:
Operate porthole door
Single knob operation
Set spin speed of 1200 RPM
Set water consumption
Interpret Fault indicators
Interpret Self diagnostics
Remove top access panel
Access lint filter
203

FIG. 2


CONTROL NOB
Advanced Novotronic controls
Single knob operation
A durable plastic material with bright finish and molded easy-grip handle and easy to read indicators.
Order spare control knob now
Troubleshoot control knob problems
Functionality:
Extended wash programs
Quick Wash 105°F program
Short wash program
Gentle Wash option
Prewash option
Spin
Rinse
Fill
Actions:
Single knob operation:
Turn dial clockwise to the desired setting indicated on the surrounding decal.
Caution: Avoid counterclockwise action, and take care to point the red indicator towards the desired portiion of the surrounding indicator.
Error conditions:
knob will not turn
knob is missing
knob turns, but no response from system
Washing machine
Control panel
Control knob

FIG. 3


Filter
Miele Novotronic W 1903
Filter System
The easy to clean lintfilter removes loose fibers and other objects from the wash water.
This filter unscrews to be cleaned easily under a faucet.
Animate removal/cleaning
Order spare lint filter now
Troubleshoot lint filter problems
Housing body
Lint Filter Access panel
Lint Filter

FIG. 4


ANIMATION
RENDERING
ORDER
DOCUMENT
FUNCTIONALITY
ACTION
SUB-ACTIONS
ERROR STATE
EFFECTS
UNIT
SUB-UNITS

FIG. 5

```
<de.janet.app.unit.Unit ID="Engine">
        <name>Engine</name>
        <orderInfo>
          <de.janet.app.unit.OrderInfo>
            <orderId>00010000</orderId>
                                    <quantity>1</quantity>
          </de.janet.app.unit.OrderInfo>
        </orderInfo>
        <renderInfo>
          <janet.topas.components.TCRenderInfo>
            <viewpointPosition value="translation = (5.4827591378103016,
2.3270326577646596, 2.1217998786636603), rotation = (-.4635803440736771,
0.8584582069714881, 0.21941473965232666, 0.89959721191091)"/>
          </janet.topas.components.TCRenderInfo>
        </renderInfo>
        <technicalData>
           <de.janet.app.unit.TechnicalData>
            <content><![CDATA[The engine gives a car the power to
go]]></content>
           </de.janet.app.unit.TechnicalData>
        </technicalData>

        <subunits>
          <!--INCLUDE cylinderhead/cylinderhead.tml-->
          <!--INCLUDE engineblock/engineblock.tml-->
          <!--INCLUDE distributingbox/distributingbox.tml-->
          <!--INCLUDE oelfilter/oelfilter.tml-->
          <!--INCLUDE generator/generator.tml-->
          <!--INCLUDE clutch/clutch.tml-->
          <!--INCLUDE gearbox/gearbox.tml-->
        </subunits>
      </de.janet.app.unit.Unit>
```

FIG. 6